




NGTS V2 CODE HANDSET TO RECEIVER

1. Carefully remove the light cover by pulling down on tab near front of unit
2. Press the LEARN button once
 - A red light will illuminate
3. Press the large button on the handset once and hold until red-light on receiver board turns off
 - This confirms that the handset is programmed (Always use the large button for coding, even if configured to use small buttons for normal operation)



Note: To reset the receiver press and hold the learn button (2.) for 12 seconds. This will erase all handsets from the memory. This is recommended if a remote has been lost or stolen. Any other handsets previously used will need to be reprogrammed by following steps 1, 2 and 3 above.